


Wall-hung boilers (electric)

18KE/14 Ray RU,UA

06 - Heat exchanger



50 - 0 - 06 - 01

Wall-hung boilers (electric)

18KE/14 Ray RU,UA


06 - Heat exchanger

Поз.	Артикульный номер	Описание	Указание, замечание
01	0010026207	Heat exchanger	18KE/14 Ray RU,UA
02	0020265335	Insulation	
03	0020094647	Heating element, 6kW with wires	18KE/14 Ray RU,UA
04	0020034829	O ring 45x5 (set 5 pc)	
05	0020094666	Thermostat, bim. 100 degC	
06	0010026078	Screw, (PK10)	
07	05493300	Screw, (x25)	
08	0020153337	Springclip, ST	

Wall-hung boilers (electric)

18KE/14 Ray RU,UA

07 - Casing parts



50 - 0 - 07 - 01

Wall-hung boilers (electric)

18KE/14 Ray RU,UA


07 - Casing parts

Поз.	Артикульный номер	Описание	Указание, замечание
01	0020211614	Front panel	with part 10
02	0020211615	Side panel	with part 10
03	0010026213	Cover plate	with part 10
04	0020043720	Set - hanging v.17	
05	0010028700	Retainer	
06	0010026216	Base plate	with part 10
07	0020273336	Clamp, (x5)	
08	0020033220	Bushing AL GP 21	
09	0020033218	Bushing AL GP 13,5	
10	0020175576	Screw, (x10)	
11	0010025887	Grommet for pipe	
12	0020140934	Company plaque Protherm	

Wall-hung boilers (electric)

18KE/14 Ray RU,UA

08a - Hydraulic parts



50 - 0 - 08 - 02

Wall-hung boilers (electric)

18KE/14 Ray RU,UA


08a - Hydraulic parts

Поз.	Артикульный номер	Описание	Указание, замечание
01	0010025841	Pump	with parts 13,15,16,17
02	0020097328	Expansion vessel	
03	0010025882	Automatic air vent	
04	0010025850	Tube	with part 12
05	0020272907	Flexible tube	
06	0010025847	Tube	with parts 12,13,17
07	0010026152	Flexible tube	
08	0020047005	Pressure relief valve, 3 bar	
09	0020079644	Sensor	
10	0010025862	Hose	
11	0020047027	Sensor, NTC	
12	0020039740	Gasket, (x5)	
13	0020014175	O-ring, (x10)	
14	0020097202	O-ring, (x10)	
15	0020014177	O-ring, (x10)	
16	S5466200	Clip, 10 mm, (x10)	
17	S5465700	Clip, 18 mm, (x10)	
18	0020047019	Clip, (x10)	
19	0010025860	Adapter	with parts 15,18
20	0020172910	Pressure gauge	

Wall-hung boilers (electric)

18KE/14 Ray RU,UA

08b - Connection parts



50 - 0 - 08 - 03

Wall-hung boilers (electric)

18KE/14 Ray RU,UA


08b - Connection parts

Поз.	Артикульный номер	Описание	Указание, замечание
01	0010027587	Kit, 3-way valve FUGAS	accessory, cannot be delivered as spare part
02	-	-	not available
03	0020025278	Motor, 3way valve	
04	0020027610	3-WAY VALVE	
05	0020174087	2.7kohm NTC sensor for external tank	accessory, cannot be delivered as spare part
06	0020027665	Sealing ring 24x15x2, (x10)	
07	0020033430	Clip to electromotor block	
08	0020033838	Plastic cable grommet	
09	0010031634	Cable	
10	0020034698	T-PART BOILER CONNECTION	
11	-	-	not for these appliances

Wall-hung boilers (electric)

18KE/14 Ray RU,UA

12 - Control box



50 - 0 - 12 - 01.01

Wall-hung boilers (electric)

18KE/14 Ray RU,UA

12 - Control box

Поз.	Артикульный номер	Описание	Указание, замечание
01	0010025867	Control panel	
02	0010025889	Display	
03	0010025877	PCB	18KE/14 Ray RU,UA
04	0020025215	Contactora ISCH 25A	
05	0010026180	Clamp	grey
06	0010026183	Clamp	PE
07	0010026177	Clamp	blue
08	0010026186	Clamp	
09	0010026189	Clamp	
10	0010026174	Jumper	
11	0020044646	Plastic distance spacer	
12	0010025871	Cable	
13	0010026160	Wiring harness	
14	0020033905	Wire Q027 VJ	
15	0020104971	Spring clip	
16	0020095625	Harness, contactor 18-21K13	18KE/14 Ray RU,UA
16	0020094671	Harness, contactor 18-28K13	18KE/14 Ray RU,UA
17	0010026086	Wiring harness	18KE/14 Ray RU,UA
18	0010026163	Cable	
19	0010026166	Cable	
20	0010026169	Cable	
21	0010026155	Cable tie	
22	0020211637	Support	
23	0010032081	Bridge	